

Instructions for use of the UBC-03 belt clip

1. Attaching the clip to a belt

- The clip can be attached to a belt by slipping the belt through the opening in the clip. If the clip is not fixed firmly on the belt, first loosen both screws **B**. After that, move the slider **A** so that the opening for belt fits the width of your belt. Then tighten thoroughly both screws **B** to prevent their spontaneous release – see *picture 1*.
- **BEWARE!** The clip has been designed for the most common kinds of belts of the width **from 32 to 50 mm** (after the removal of the clip's adjustable stop **up to 60 mm**). The clip may not be attachable to atypical belts – the extremely wide or, in contrast, extremely narrow ones. Belts made of too thin or inappropriately thick materials can also create difficulties for the easy carrying or attaching of the clip!

2. The holder angle adjustment

- The holder can be smoothly **rotated in the range of 360 degrees** without the use of any tool (there are 16 possible fixed positions).
- The resistance of the rotary mechanism can be adjusted, when **the turning is too difficult** (or too easy). This is done by slight loosening or tightening of the fixing bolt **H** with a Phillips screwdriver so that the resistance force of the rotary mechanism suits your needs. The bolt **H** is located on front or rear side of the holder (according to the holder type) – see *pictures 2 and 3*.
- **BEWARE!** In the case of holders where the access to the screw **H** is possible from the back (see *picture 3*), it is necessary to set the resistance of the rotary mechanism **BEFORE** the holder is attached to the belt.

